
Quick Install Guide

Ubiggid


ubicquia

Contents



*OBS: Installation guide for de-energized units

1. Installing the Bracket



1a

Mount bracket to the open arrester provisions. (Can be either side).

1b

1c

Adjust mounting bracket up or down so the top is level with the pressure release valve. Tighten screws.


m R Λ

ŧα.

2. Scanning the Sensor Unit

2a

Turn sensor unit over to reveal and scan the QR code. This is unique to each device confirming installation.




2b


Locate barcode on transformer and scan as well.

2c


The two units are now paired to one another.




3. Installing the Sensor Unit



4. Installing the Pressure Transducer



5. Installing the Wire Connectors





5a

Showing all three power wire connectors: blue (line 1), white (neutral) and red (line 2). *OBS: During install, wires can freely touch surfaces.

5b

Remove pre-assemble washer and nut from bushing eye bolt.





5c


Slide the power eyelet onto bushing eye bolt followed by a washer, and a nut.




Screw the nut until the components are properly tightened on the eye bolt.


5e

Repeat step 5a-5d for the remaining two power wires.





6. Installing the Rogowski Coils



6a


The blue (line 1) and red (line 2) power wires must have the matching Rogowski coils installed on the bushings.


6b


Wrap the Rogowski coil around the bushing eye bolt, behind the wire assembly.


6c


Connect the Rogowski cable ends together by inserting and then twisting slightly until locked.













6d

A Rogowski holder is provided to secure the connected coil in place.

6e

Open the holder so that the top and bottom extend beyond the connected Rogowski coil.






6f

Slide the opened Rogowski holder over the Rogowski coil, ensuring the holder sits behind the bushing eye bolt and wire assembly.

6g

Nest the coil within the top and bottom pockets of the Rogowski holder.

*SHOWING BACK FACE OF COIL HOLDER



6h

The housing should close snugly around the bushing with the wires hanging freely.

6i


Fasten the holder closed with a single zip tie.

6j


With the zip tie tightened, the Rogowski coil assembly is complete.

6k

Repeat steps 6b-6j with the remaining Rogowski coil and holder. Securing it around the matching power wire assembly.



*SHOWING BACK FACE OF COIL HOLDER



7. Assembly Complete

7a

The UbiGrid DTM+ installation is complete. The transformer is ready to be installed onto a utility pole.

